



Cable For Connection Of XCOM Remote Module to XCOM Radio



3.5mm 3 Pin Plug


Note: This release of module ONLY has the first 2 Inputs operational. The software will be updated shortly to enable all 6 inputs (12 functions)



Viewing the back of the DB15 Female plug

Input 1
Input 2
Input 3
Input 4
Input 5
Input 6

0.25 amp Fuse or Circuit Breaker Must be Installed



Aircraft Battery or Power Supply

Input 1 Momentary Push

Return to main screen or toggle active and standby frequencies if already on main screen

Input 1 Long Push

Toggle View between Default and Mem View if the radio is in any other screen, it will return to Default view

Input 2 Momentary Push

Toggle Scan Mode in default view this toggles Dual Watch and in Mem View this toggles memory scanning.

Input 2 Long Push

Select next memory channel